### AT6102, A6102A, AT6102B Spectrometers



# Radionuclide Identification

#### Device

Portable multifunctional radiation monitoring devices, primarily designed for search and detection of gamma radiation sources with automatic identification of radionuclide composition.

Can be used for area and land radiation monitoring with data GPS-referencing.

AT6102 model can detect neutron radiation and measure neutron count rate.

#### Operating principle

The spectrometer operates in continuous radiation environment scan mode: search, detection, localization and identification of gamma sources; detection of neutron radiation.

When radioactive source is detected the spectrometer activates alarm and identifies its radionuclide composition.

High-sensitivity scintillation Nal(TI) gamma radaition detector is used in these devices. The spectrometer is equipped with Geiger-Muller counter with filter, which aligns energy dependence of appliance sensitivity to extend dose rate measurement range.

Two integrated proportional helium counters of slow neutrons in polyethylene moderator are used in AT6102 model.



The possibility of external detection unit connection allows measurement of alpha and beta particles flux density from contaminated surfaces (BDPA-01/BDPB-01) and neutron radiation dose rate (BDKN-03).









#### **Application**

- Unauthorized traffic control of radioactive sources and materials
- Radioactive waste control, recycling and disposal
- Radiation monitoring of ecological environment, areas and facilities
- Nuclear and radiation accidents management, radiation monitoring during decontamination operations
- Nuclear industry and Nuclear power plants
- Radiopharmaceuticals production and Nuclear medicine
- Geological survey
- Research activities

#### **Features**

- Detection of gamma, neutron, alpha and beta radiation
- Real-time spectra analysis and radionuclide identification
- Multiple functions
- Single-block design
- One-hand operation
- Automatic accommodation to change of radiation background level
- On-line and expert mode operation
- Automatic logging of scan data with GPS-referencing for further analysis
- Digital automatic LED stabilization and temperature compensation system
- Sound, visual and vibration notification
- Recording and storing measurement result and spectra in memory
- Field operation in a wide temperature range
- Instrument-to-PC data exchange over USB or Bluetooth interface
- External detection units can be connected

#### **Application software**

- «SpectEx» Real time display of data measured by instrument with further ability to process and save it into PC, as well as instrument file system management
- «GARM» Processing and analysis of stored data with display on a base map





## AT6102, A6102A, AT6102B Spectrometers

Specifications of spectrometers	AT6102 (γ, n)	ΑΤ6102Α (γ)	ΑΤ6102Β (γ)	
Gamma radiation detector	Scintillator NaI(T Geiger-Muller		Scintillator NaI(TI), Ø40x80 mm; Geiger-Muller counter tube	
Neutron radiation detector	Two <sup>3</sup> He proportional neutron counter	-	-	
Gamma radiation energy range	20 keV – 3 MeV			
Neutron radiation energy range	0.025 eV – 14 MeV	-	_	
Radionuclide identification	Medical, Industrial and Natural (Library of identified radionuclides can be modified)			
Typical resolution at 662 keV (137Cs)	7.5%			
Maximum input statistical load	≥1.5·10 <sup>5</sup> s <sup>-1</sup>			
Detectable activity of <sup>137</sup> Cs source, located at the distance of 20 cm in a time not longer than 2 s	(50±10) kBq			
Detectable activity of <sup>252</sup> Cf source, located at the distance of 20 cm in a time not longer than 5 s	1.8·10 <sup>4</sup> neutron/s (Probability of detection is 0.9)	_	-	
Measurement range of gamma radiation ambient dose equivalent rate	0.03 – 300 μSv/h [Nal(TI)] 0.03 – 150 μSv/h [Nal(TI)] 10 μSv/h – 100 mSv/h [G-M] 10 μSv/h – 100 mSv/h [G-M]			
Limit of intrinsic relative error of dose rate measurement	±20%			
Typical sensitivity to gamma radiation  241Am  137Cs 60Co	6600 cps/(μSv·h <sup>-1</sup> ) 850 cps/(μSv·h <sup>-1</sup> ) 430 cps/(μSv·h <sup>-1</sup> )		11600 cps/(µSv·h <sup>-1</sup> ) 1700 cps/(µSv·h <sup>-1</sup> ) 840 cps/(µSv·h <sup>-1</sup> )	
Response time for dose rate change from 0.1 µSv/h to 1 µSv/h	<2 s (accuracy error ≤±10%)			
Energy dependence relative to 662 keV (137Cs)	±20% [NaI(TI)] (in 50 keV – 3 MeV energy range) ±25% [G-M] (in 60 keV – 3 MeV energy range)			
Typical sensitivity to direct neutron radiation Pu-Be <sup>252</sup> Cf	0.28 cps/(neutron·s <sup>-1</sup> ·cm <sup>-2</sup> ) 0.5 cps/(neutron·s <sup>-1</sup> ·cm <sup>-2</sup> )	-	-	
Number of ADC channels	1024			
Operation mode setup time	≤1 min			
Continuous run time With external smart probes connected	≥18 h ≥15 h	≥25 h ≥17 h		
Burn-up life	≥100 Sv			
Protection class	IP65			
Working temperature range	-20°C to +50°C			
Relative air humidity	≤95% (with air temperature ≤35°C without condensation)			
Connection to PC	USB, Bluetooth			
Overall dimensions, weight	230x115x212 mm, 2.5 kg   230x115x177 mm, 1.9 kg   230x115x177 mm, 2.15 kg			
The spectrometers comply with: GOST 27451-87, Safety requirements of IEC 61010-1:2010, EMC requirements of EN 55011:2009, IEC 61000-4-2:2008, IEC 61000-4-3:2008				

Specifications of external detection units	BDPA-01 (α)	BDPB-01 (β)	BDKN-03 (n)	
Detector	ZnS(Ag) scintillator, Ø60 mm	Scintillation plastic, Ø60 mm	<sup>3</sup> He counter in polyethylene moderator	
Measurement range	0.5 – 1·10 <sup>5</sup> particle·min <sup>-1</sup> ·cm <sup>-2</sup> (Flux density)	3 – 5·10⁵ particle·min⁻¹·cm⁻² (Flux density)	0.1 μSv/h – 10 mSv/h (Dose rate)	
Energy range	4 – 7 MeV	155 keV – 3.5 MeV	0.025 eV – 14 MeV	
Sensitivity	0.15 cps/(particle·min <sup>-1</sup> ·cm <sup>-2</sup> ) ( <sup>239</sup> Pu)	0.3 cps/(particle·min <sup>-1</sup> ·cm <sup>-2</sup> ) ( <sup>90</sup> Sr+ <sup>90</sup> Y)	0.355 cps/(µSv⁺h⁻¹) (Pu-Be)	
Limit of intrinsic relative measurement error	±20%			
Protection class	IP64			
Overall dimensions, Weight	Ø85x200 mm, 0.5 kg	Ø85x205 mm, 0.55 kg	316x220x265 mm, 8 kg	

Design and specifications are subject to change without notice





